



303 MESSNER DR. • WHEELING, IL • 60090
847-459-1469 • FAX 847-459-1569
WWW.LUND-INDUSTRIES.COM

Bale Bracket Console Mount Kit

- 1) Attach one (1) bale bracket to front of console.
- 2) Attach one (1) bale bracket to back of console.
- 3) Attach brackets to floor.

CAUTION: USE SHORTEST SCREW POSSIBLE TO ATTACH TO FLOOR; DO NOT SCREW THRU TRANSMISSION.

Caution: Be sure not to drill or screw into anything under the carpet or transmission hump (wires, lines, etc.) when mounting the console. Be sure that any wiring leaving the console is protected from sharp edges by flex guard wire loom or a similar material. Late models of the Ford Crown Victoria and Taurus have plastic rear heating vents on the transmission hump. When securing the console in these vehicles – seat bolt mounting brackets should be used.