



---

---

303 MESSNER DR. • WHEELING, IL • 60090  
847-459-1469 • FAX 847-459-1569  
WWW.LUND-INDUSTRIES.COM

---

---

## Crown Victoria Slide-Out Tray CCV-TRAY-21 CCV-TRAY-25 Installation Instructions



**CCV-TRAY-25**  
(15" x 25")



**CCV-TRAY-21**  
(15" x 21")

1. Align forward radio shelf bracket with existing holes in front on trunk wall. Use (2) two ¼ x 1" hex head cap screws, (2) two ¼" flat washers and (2) two ¼" Nylok nuts. (Included) Do Not fully tighten bracket.
2. Use a shim to level radio shelf. Drill ¼" hole into trunk hinge, support base on driver's side. Fasten down shelf using (1) one ¼ x 1" hex head cap screw, (1) one ¼" flat washer, and (1) one ¼" Nylok nut. (Included)
3. Insert (2) two ¼ x 1" hex head cap screws in shelf holes. Place bottom support bracket over hex head cap screws, then place hanger support bracket on top of bottom bracket. Place (2) two ¼" flat washers and (2) two ¼" Nylok nut over screws and tighten. (Included) NOTE: '98 Crown Victoria use pair of holes toward front of vehicle; '97 Crown Victoria use holes toward rear of vehicle.
4. Using the support as a template mark and drill (2) two holes in upper deck. Bolt support bracket on with ¼ x 1" hex head cap screw, (2) two ¼" flat washers and ¼" Nylok nuts. (Included) Make sure shelf is level. Tighten all hardware.

**NOTE: Do not substitute hardware. Do Not use self-tapping screws as they will vibrate loose.**