



---

---

303 MESSNER DR. • WHEELING, IL • 60090  
847-459-1469 • FAX 847-459-1569  
WWW.LUND-INDUSTRIES.COM

---

---

## **Extended Base for 900 Console Installation Instructions**

**CAUTION: EXTREME CARE MUST BE TAKEN TO ENSURE THAT EQUIPMENT IS NOT MOUNTED IN THE AIR BAG DEPLOYMENT ZONE AS DEFINED BY THE VEHICLE MANUFACTURER.**

- 1) Determine the best location for mounting the base in your vehicle based on equipment accessibility and visibility. The hinge on base faces the rear of the vehicle.
- 2) Mount base to floor of vehicle using #14 Sheet Metal Screws or Bolts. (User supplied because of varying lengths needed)

**CAUTION: BE SURE NOT TO DRILL OR SCREW INTO ANYTHING UNDER THE CARPET OR TRANSMISSION HUMP (WIRES, LINES, ETC.) WHEN MOUNTING THE CONSOLE. BE SURE THAT ANY WIRING LEAVING THE CONSOLE IS PROTECTED FROM SHARP EDGES BY FLEX GUARD WIRE LOOM OR A SIMILAR MATERIAL.**

- 3) Attach 900 Console to base using 5/16 bolts and oval mounting brackets.
- 4) When wiring console equipment be sure to leave enough slack to allow console to be tipped back on hinge for repairs.

Optional: Bale Brackets (p/n CC-BALE) are available to mount extended base to metal floor plates.