



303 MESSNER DR. • WHEELING, IL • 60090
847-459-1469 • FAX 847-459-1569
WWW.LUND-INDUSTRIES.COM

2000 - 2002 Ford Expedition No Holes Console Mount bracket

1. Remove front inside seat bolts. (Transmission Side)
2. Place mount bracket on **top** of seat rails.
3. Use 3/8" washers as shims to take up gap between seat rail and Lund Bracket.
4. Install factory bolts and washers and tighten securely.
5. Mount console to bracket using bail "U" bracket & hardware provided.
6. Secure rear of console with large rear "L" bracket.

Caution: Be sure NOT to drill or screw into anything under the carpet (wires, lines, etc.) when mounting the console.