



303 MESSNER DR. • WHEELING, IL • 60090
847-459-1469 • FAX 847-459-1569
WWW.LUND-INDUSTRIES.COM

HAT- 35 and HAT- 47

INSTRUCTIONS

1. Install Tilt/Swivel Clevis to Hat using supplied Hardware. One Nylon Washer fits on top of Hat and Under Tilt Swivel Clevis. The Second Nylon Washer goes under top Of Hat followed by the Steel Washer.
2. Position the Hat on Console and Drill 4 holes for Mounting. Use At least ¼ x 20 Bolts and Nylok Nuts.
3. The Height can be adjusted by unbolting and then raising or lowering the 2 pieces of the Hat.

Caution: Extreme care must be taken to ensure that equipment is not mounted in the air bag deployment zone as defined by the vehicle manufacturer.