



303 MESSNER DR. • WHEELING, IL • 60090
847-459-1469 • FAX 847-459-1569
WWW.LUND-INDUSTRIES.COM

MW-Base for MW-520 Workstation Mount Installation Instructions

1. Install MW-520MT to base using supplied Hardware. One Nylon Washer fits on top of Base and Under Tilt Swivel Clevis. The Second Nylon Washer goes under top Of Base followed by the Steel Washer.
2. Position MW-520MT and Base on Console and Drill 4 holes for Mounting. Use At least ¼ x 20 Bolts and Nylok Nuts.
3. Height of MW-520MT can be adjusted by raising or lowering the 2 pieces of the MW Base.
4. The 1" black nylon washers are shims which fill any gaps between the MW BASE and the CPU.

Important: MW Base is designed to hold the CPU only!
Radio Amp should be mounted elsewhere since access to it is not normally needed.

Caution: Extreme care must be taken to ensure that equipment is not mounted in the air bag deployment zone as defined by the vehicle manufacturer.