



303 MESSNER DR. • WHEELING, IL • 60090
847-459-1469 • FAX 847-459-1569
WWW.LUND-INDUSTRIES.COM

SUTA-BASE Base Plate 2001-3 Tahoe/Suburban

Installation Instructions

- 1) Remove factory console and brackets.
- 2) Remove inside rail seat bolts for both seats.
- 3) Position four (4) legs under seat rails and install seat bolts loosely.
- 4) Position and attach base plate to legs using 3/8" bolts and flange nuts. Base plate goes on Top of legs. Flange nuts should be on the bottom.
- 5) Tighten ALL bolts and hardware.