



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

Installation Instructions For 2002-Newer Dodge Ram 1500 & 2003-Newer Dodge Ram 2500 or 3500 FP-116 Base

The FP-116 ('02+ Ram 1500 & '03+ Ram 2500 or 3500) is a no-holes passenger side base. Installing a no-holes base does not require drilling any holes into the vehicle.

Installing the FP-116 in the vehicle:

1. Remove the offset riser from the base. See figure 1. (The offset riser and base are assembled at the factory to make packaging and shipping easier, but need to be disassembled to install the base.)
2. Move the passenger seat as far back as possible. Remove the bolts that fasten the front of the passenger seat brackets to the vehicle floor.
3. Without moving the seat, place the base over the front of the seat bracket and re-install the seat bolts.
4. Attach pole assembly to offset riser using hardware supplied with the pole assembly.
5. Attach offset riser to base with (4) 3/8-16 x 3/4" hex head bolts and 3/8 flat washers.

