



303 MESSNER DR. • WHEELING, IL • 60090  
 847-459-1460 • FAX 847-459-1569  
 WWW.LUND-INDUSTRIES.COM

## Installation Instructions For 1995-Newer Chevy S-10 Blazer & GMC Jimmy FP-120 Base

The FP-120 ('95+ S-10 Blazer & '95+ GMC Jimmy) is a no-holes passenger side base. Installing a no-holes base does not require drilling any holes into the vehicle. The base utilizes an offset riser to position the pole closer to the transmission hump.

### Installing the FP-120 in the vehicle:

1. Attach the offset riser to the base with the (4) 3/8unc x 3/4" carriage bolts, flat washers and hex nuts that were provided. See figure 1.
2. Remove the front two seat nuts that hold the passenger seat to the floor.
3. While lifting upward on the front of the seat, place the base over the floor studs so the studs protrude through the base.
4. Lower the seat back into place.
5. Re-install the two seat nuts that were removed in step 1.

