



303 MESSNER DR. • WHEELING, IL. • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

Installation Instructions For 2000-Newer Chevy C/K 25-3500 FP-122 Base

The FP-122 (2000-Newer Chevy C/K 25-3500 base) is a no-holes base. The base mounts between the upper portion of the passenger seat track and the seat cushion.

Installation of the FP-122: (See Figure 1)

1. Remove the (2) front 5/16" hex nuts that hold the passenger seat cushion to the seat track brackets.
2. Lifting on the front of the seat cushion, separate the front of the seat from the seat track brackets.
3. Position the FP-122 on top of the seat track brackets so the slots in the FP-122 line up with the holes in the seat track brackets.
4. Lower the seat cushion back into place, allowing the studs to pass through the holes in the FP-122 and seat track brackets.
5. Re-attach the (2) 5/16" hex nuts that were removed in step 1.

