



---

---

303 MESSNER DR. • WHEELING, IL • 60090  
847-459-1460 • FAX 847-459-1569  
WWW.LUND-INDUSTRIES.COM

---

---

## Installation Instructions For 2004-Newer Ford F150 FP-124 Base

The FP-124 (2004 & newer Ford F150) is a no-holes passenger side base. Installing a no-holes base does not require drilling any holes into the vehicle. The base mounts under the seat bracket and is compressed to the floor using the seat bolts.

### Mounting the FP-124 to the passenger seat:

1. Attach the FP-Step to the lower bracket with the 3/8" carriage bolts, flat washers and nuts.
2. Remove the two front seat bolts that attach the passenger seat to the floor.
3. Lift upward on the front of the passenger seat and slide the lower bracket under the seat until the slots in the lower bracket line up with the holes for the seat bolts. Lower the seat back into position.
4. Install the two front seat bolts that were removed in step 2. The lower bracket should now be compressed between the seat and the floor.

