



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

Installation Instructions For 1995-Newer Ford Econoline Van FP-128P Passenger Side Base

The FP-128 (1995 & newer Ford Econoline van) is a no-holes base. Installing a no-holes base does not require drilling any holes into the vehicle. The base mounts in between the passenger side seat bracket and the floor pan using the hardware that fastens the seat bracket to the floor. The base mounts between the driver and passenger seats.

Mounting the FP-128P to the passenger seat:

1. Remove the inboard seat bolt and nut from the inboard passenger side seat bracket that attaches it to the floor.
2. Loosen or remove the outboard seat bolt and nut from the outboard passenger side seat bracket that attaches it to the floor.
3. Remove the seat or lift upwards on the inboard side of the passenger seat and slide the base under the seat bracket until the slots line up with the holes for the seat bolts. Lower the seat back into position.
4. Re-install the hardware that was removed in steps 1 and 2. The base should now be compressed between the seat bracket and the floor
5. Loosen the two hex nuts that fasten the brace angle to the pole gusset and adjust the brace angle to come into contact with the vehicle seat bracket. Tighten the two bolts.

