



303 MESSNER DR. • WHEELING, IL • 60090
847-459-1460 • FAX 847-459-1569
WWW.LUND-INDUSTRIES.COM

Installation Instructions For FP-52 Universal Flat Floor Base

1. Place the base on the floor so the post is in the desired location.
2. Drill $17/32$ " holes in the floor at each mounting hole location, using care not to damage any equipment that may be under the floor. Most bases have holes for $3/8$ " bolts, but holes for $1/2$ " bolts are furnished in the taller bases.
3. Place the bolts in the holes, add nuts and washers and tighten. If the floor is less than $1/4$ " thick, we recommend using fender washers on the bottom side. *Do not use lag screws or sheet metal screws, as these can pull out of the floor.*
4. To adjust the height of the post, loosen the bolt at the top of the post one turn. If necessary, tap lightly on the top of the bolt to release the top plate. Adjust the height and direction of the top plate and re-tighten the bolt.

