



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

Installation Instructions For Ford Police Interceptor FP-59 Base

The FP-59 (Ford Police Interceptor base) is a no-holes passenger side base. The base consists of two main components: a base and an adjustable upper tube assembly. Installing a no-holes base does not require drilling any holes into the vehicle.

Installing the FP-59 Base in the vehicle:

1. Place the passenger seat in its most rearward position. Remove the hardware that fastens the seat brackets to the vehicle floor pan.
2. Place the mount in the passenger footwell with the slotted mounting holes positioned towards the seat and the pole next to the transmission hump.
3. Tilt the seat back and slide the base in between the seat bracket and the vehicle floor pan. Make sure to line up the holes in the base with the seat bracket holes.
4. Re-install the seat bracket hardware removed in step 1 and tighten. The base should now be held firmly in position.

Installing the head and adjusting the mount:

1. If not already done, install the head or rack on the base following the instructions furnished with the head or rack.
2. Loosen the bolt at the top of the post one turn. If necessary, tap the top of the bolt until the upper part of the tube assembly moves freely within the lower part.
3. Adjust the assembly to the desired height, point the post top plate directly towards the back of the car, and tighten the bolt.
4. Pivot and tilt the head to all possible positions (see instructions for head) and check for comfortable reach and clearance with the dash and other obstructions and adjust if necessary.

