




---



---

303 MESSNER DR. • WHEELING, IL • 60090  
 847-459-1460 • FAX 847-459-1569  
 WWW.LUND-INDUSTRIES.COM

---



---

## Installation Instructions For 1996-Newer Chrysler Minivan FP-60 Base

The FP-60 (1996 & newer Chrysler Minivan) is a no-holes base. Installing a no-holes base does not require drilling any holes into the vehicle. The base mounts between the driver side and passenger side seats using the existing driver side seat bolts. The use of a Brace2 support brace is required for maximum rigidity.

### Installing the FP-60 Base in the vehicle:

1. Remove the bolts that fasten the right side of the driver's seat bracket to the vehicle floor pan.
2. Assemble the legs to the base with the supplied hardware as shown in figure 1. Do not firmly tighten the pieces together at this point.
3. Place the mount to the right of the driver's seat and position the base and legs so the slots in each leg bracket line up with the seat bolt holes. Tighten the pieces together.
4. Without moving the seat, place the leg brackets under the seat bracket and re-install the seat bolts. Pressing the base down into the carpeting may be needed to align slots and seat bolts.
5. The remaining hardware is for attaching the Brace2 to the passenger left side seat track. Insert the square nut into the upper portion of the seat track and place the large flat washer on top of the track. Insert the 1/4-20 x 1/2 hex bolt through the Brace 2 end and tighten to the square nut.

Figure 1

