



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

Installation Instructions For 1997-Newer Dodge Durango & Dakota FP-DUR Base

The FP-DUR is a no-holes base designed to fit into 1997 & newer Dodge Durango & Dakota vehicles with bucket or split bench seats. Installing a no-holes base does not require drilling any holes into the vehicle.

Installing the FP-DUR Base in the vehicle:

1. Move the passenger seat back as far as possible. Remove the bolts that fasten the front of the passenger seat brackets to the vehicle floor pan.
2. Without moving the seat, place the base over the front of the seat bracket and re-install the seat bolts. Due to the limited space under the base it is easier to add the gusset and pole assembly after the base piece is mounted.
3. Attach the gusset to the stud on the base with 1/4–20 nylok nut and 1/4" flat washer.
4. Place the pole assembly on the base, as shown, and install (2) 3/8-16 x 1" hex head bolts with 3/8 " flat washers through the holes in the pole and base and into the pems in the gusset. Install (2) 3/8-16 x 3/4" hex head bolts with 3/8" flat washers through the holes in the pole and into the pems in the base. Tighten all bolts holding the base, gusset and pole together.
5. Attach the motion attachment, mount head, computer mount, keyboard mount, etc. to the pole assembly according to the instructions supplied with that product.

