



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

Installation Instructions For 1994-Newer Dodge Ram Truck FP-RAM Base

The FP-RAM (1994-Newer Dodge Ram Truck base) is a no-holes base. The base consists of two main components: a base with an extension plate and a pole assembly. Installing a no-holes base does not require drilling any holes into the vehicle.

Attaching the extension plate:

1. Attach the extension plate to the bottom side of the base, in four places as shown in diagram, using the hardware supplied with the base.

Installing the FP-RAM Base in the vehicle:

1. Place the bench seat or both bucket seats in their most rearward position. Remove the hardware that fastens the front of the seat brackets to the vehicle floor pan.
2. Place the base over the transmission hump with the slotted mounting holes facing toward the seat.
3. Tilt the seat back and slide the base in between the seat bracket and the vehicle floor pan. Make sure to line up the holes in the base with the seat bracket holes. On 1994 – 98 model trucks, the slot toward the inside on the driver's side will be used. On 1999 – newer model trucks, the slot toward the outside on the driver's side will be used.
4. Re-install the seat bracket hardware removed in step 1 and tighten. The base should now be held firmly in position.

Installing the pole assembly:

1. Attach any motion attachments, mount heads, NotePad or NotePort products to the pole assembly according to instructions supplied with them.
2. Position the completed pole assembly on the extension plate and attach using the hardware supplied with the pole assembly.
3. Pivot and tilt the head to all possible positions (see instructions for head) and check for comfortable reach and clearance with the dash and other obstructions and adjust if necessary.

