



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

Assembly Instructions For The SCN-SPT Adjustable Laptop Screen Support

To assemble any or all of the options listed, follow these three steps first:

1. Place the computer into the ULTP4 as if it were being installed.
2. Determine the location of any optional equipment and mark the location on the ULTP4 with tape or washable marker. (**IMPORTANT:** Only install the options on the ULTP4 that **do not interfere** with safe operation of the vehicle.)
3. Remove the computer.

Assembly of the SCN-SPT:

1. The screen support is designed and assembled to attach to the left side of the ULTP4. If it is desirable to attach the support to the right side of the ULTP4, skip to step 4.
2. Attach the screen support to the ULTP4 using the two 8-32 x 5/8" socket head machine screws provided (see Figure 1).
3. Position the pivot screw near the pivot point of the screen. (The mounting bracket can be positioned away from the pivot point to eliminate interference with the computer ports.)
4. For right hand mounting of the screen support, minor disassembly and re-assembly of the support is required. Remove the pivot screw, hand knob, shoulder washer, and (2) flat plastic washers. (Note: the threads of the pivot screw are treated with reusable thread-locking compound, do not clean the threads.)
5. Re-assemble the screen support as shown in Figure 2. Do not over tighten; the pivot arm must move freely when the hand knob is loosened. Proceed with steps 2 and 3.

