



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

AR-DUR12 2012 Dodge Durango Console Installation Instructions



Secure front of Lund console w/ supplied hardware

- 1: Remove factory shift knob.
- 2: Use a small flat head screwdriver to pry down chrome bezel. Use extra caution. Remove the retaining clip and then slide shifter off of shaft.
- 3: Remove front portion of factory console. Be certain to disconnect factory wire harnesses.
- 4: Remove all factory screws and bolts to remove rear section of factory console. Then replace the front section of the factory console.
- 5: Place Lund console over the rear area of the factory console.
- 6: Use the two factory bolts at bottom of console to attach the Lund console to the factory base. Secure the front of the Lund console with supplied 10-32 x 1.5" flat head screw through the hole in the front section of the factory console with fender washer and nylok beneath.

Carefully remove chrome bezel



Secure sides of Lund console w/ 2 factory bolts (1 on ea. side)



Be careful not to pinch any wiring beneath or between console while installing.