



---

---

303 MESSNER DR. • WHEELING, IL • 60090  
847-459-1469 • FAX 847-459-1569  
WWW.LUND-INDUSTRIES.COM

---

---

## LKP-FLR Keyboard with Adjustable Pole Installation Instructions

The LKP-FLR is a universal adjustable keyboard pole assembly for mounting on the passenger side of the vehicle. It features adjustable height with a locking handle and locking articulating arm assembly for connection to the KBAD Universal keyboard tray or other components.



1. Installing the mount in a Ford Crown Victoria does not require drilling any holes in the vehicle.
2. Place the passenger seat as far to the rear as possible. Remove the front hardware that secures the seat to the floor pan.
3. Position the LKP mount next to the transmission hump so that the ob-round hole and the support bracket hole line up with the holes in the seat bracket.
4. Tilt the seat back and slide the mount base and support bracket between the seat and floor.
5. Re-install the seat hardware removed in step 2 and tighten. Also tighten the support bracket.

For installation on other vehicles, the floor pan may need to be drilled and the base and support secured with bolts and nuts or #14 hex washer head sheet metal screws.

The keyboard tray or other component can now be attached to the LKP assembly. The articulating arm allows a wide range of adjustment for either the passenger or the driver and must be **locked** while driving.

**IMPORTANT NOTICE:** Lund Industries, Inc. has no control of the configuration or dimensions of equipment installed, nor the configuration of vehicles or their air bag deployment zones. Likewise, we have no control over the installation of the Control-Com Consoles and Mounting Systems. The sole responsibility for keeping equipment out of air bag deployment zones is the users. Users are urged to check all installations against the vehicle manufacturer's definition of their airbag deployment zone. Lund Industries, Inc. assumes no liability for non-compliant installations.

For further information and customer support please call Lund at 800-504-1460.