



303 MESSNER DR. • WHEELING, IL • 60090
 847-459-1460 • FAX 847-459-1569
 WWW.LUND-INDUSTRIES.COM

AR-EXPL11 2011 Civilian Explorer Console Installation Instructions



- 1: Carefully loosen factory console top and side plastic trim pieces.
- 2: Unsnap and remove the 2 front latching mechanism pieces.
- 3: Unscrew sensor from bottom of inner carpeted liner and remove inner liner leaving sensor at the bottom of the well. (Secure sensor to bottom of well with supplied Velcro.)
- 4: Unscrew and remove the factory armrest.
- 5: Set Lund console over armrest well and secure with (2) factory screws in front & (2) supplied 8-32 x 2 1/2" screws in the back.

Remove tab if needed for
 Equipment clearance



Factory mounting screws

Supplied mounting screws

